



South Jersey Party Rentals Inc.

Directions for Propane Convection Oven

1. Open Propane Valve (make sure regulator is pointing away from the unit)
2. Turn the gas switch to ON on the front of the oven.
3. Set Desired Temp
4. Set Blower to ON
5. Set Cool Down Switch to Auto
6. Unit will try to light. You should hear a clicking sound from the electronic ignition. The unit will not light the first time due to the air in the line from delivery. Let it attempt to light for at least 90 seconds then turn the blower to the off position.
7. Wait 60 seconds then turn the blower switch ON and the unit should light. There is an orange indicator light that will turn on once the unit is lit. If the unit does not light then repeat Step 6.
8. If it does not light on the third attempt please call support at 609.820.3724.